

Instructions - #TLW8S


(A) Battery Installation

Remove the bottom of the case, install 6V batteries, (TLW8S will operate with one or two) and snap the case top back on. The orientation of the spring terminals on the batteries does not matter.




(B) Operation


With the front of the light (label/diamond-shaped nut side) facing forward, use the included key to turn the light on by inserting it into the hole on the right side of the light and pushing in. Pushing in from the left side turns the light off. Select the operating mode by inserting the key into the hole at the front of the light case and pushing it in. TLW8S has two operating modes when switched on, **Flash** and **Steady Burn**. Pushing the switch in toggles between the modes.



(A)



(B)



Note: Be sure to test the unit in natural light, fluorescent lighting may not trigger the light sensor.